



STEP 1

Preparation & Cleaning

Make sure the old tiles are firmly attached to the wall. Thoroughly clean the wall with a good degreaser (e.g., St. Marc or ammonia) and dry it completely. A clean surface is key to good adhesion.



STEP 2

Measuring & Cutting

Measure the wall. Dizzplace PVC panels are only 3 mm thick, making them very easy to cut to size. Use a sharp utility knife (score and snap) or an angle grinder with a diamond blade.



STEP 3

Applying Adhesive

Apply high-quality polymer adhesive (High Tack) to the back of the panel. Use a zigzag or dot pattern to ensure even distribution of the adhesive across the entire panel.



STEP 4

Positioning & Pressing

Press the panel firmly against the old tiled wall. Thanks to its thickness of just 3 mm, you virtually lose no space in your bathroom while gaining a modern, seamless design.



STEP 5

Waterproof Sealing

Neatly finish the corners, floor edges, and joints around the shower tray or bathtub using mould-resistant sanitary silicone in a matching colour. This guarantees a 100% waterproof seal.